

**Dual-spectrum
Turret Network Camera
User Manual V1.0.0**



Statement

The copyright of this manual belongs to the equipment manufacturer. Without the written permission of the manufacturer, no one shall copy, photocopy, translate or disseminate all or part of this manual.

The contents of this manual will be changed from time to time due to product version upgrades or other reasons, and subject to change without notice. We try our best to ensure that the content in this manual is accurate and reliable. This manual is only used as a guide. All statements, information and suggestions in this manual do not constitute any express or implied guarantee.

Special Statement

Please strictly abide by the applicable laws and regulations for the use and maintenance of the monitoring interface. Using equipment for illegal purposes or snooping on the privacy of others are all illegal surveillance.

Symbol Description

For the symbols that appear in the document, the description is as follows.



Cautions: general warning signs, reminding things that should be paid attention to during operation.



Instructions: instructions are an emphasis and supplement to the main text.

Default Information:

The default super administrator account of the device: admin.

The default super administrator password of the device: admin.

The default IPv4 address of the device: 192.168.1.123.

Table of Contents

1. Camera Login.....	1
2. Preview.....	2
3. Temperature Measurement.....	4
3.1 Basic Parameters.....	4
3.2 Cold Hot Tracking.....	5
3.3 Thermography Analysis.....	8
3.3.1 Measurement List.....	8
3.3.2 Temperature Measurement Drawing.....	11
4. Smart Analysis.....	13
4.1 General Behavior Analysis.....	13
4.1.1 Trip Wires Intrusion.....	13
4.1.2 Region Intrusion.....	14
4.1.3 Global Config.....	16
4.2 Fire Warning.....	17
4.2.1 Fire Alarm.....	17
4.3 Alarm Input.....	18
4.4 Burning Alarm.....	19
4.5 Exception Handling.....	21
4.5.1 SD Card Exception.....	21
4.5.2 Network Anomaly.....	21
4.5.3 Illegal Access.....	21
5. Settings.....	21
5.1 Camera Settings.....	21
5.1.1 Camera Parameters.....	21
5.1.2 Video.....	26
5.1.3 Audio.....	34
5.2 Network Settings.....	35

5.2.1 TCP/IP.....	35
5.2.2 DDNS.....	37
5.2.3 SMTP.....	37
5.2.4 UPnP.....	39
5.2.5 FTP.....	40
5.2.6 Platform.....	41
5.3 Peripherals Settings.....	42
5.3.1 Filling Light.....	42
5.4 Storage Management.....	43
5.4.1 Storage Device.....	43
5.4.2 Video Control.....	43
5.4.3 Video Plan.....	44
5.4.4 Capture Plan.....	45
5.5 System Management.....	47
5.5.1 Local Setting.....	47
5.5.2 User Management.....	49
5.5.3 Safety Management.....	51
5.6 System Maintenance.....	52
5.6.1 Auto Maintenance.....	52
5.6.2 Backup and Restore.....	53
5.6.3 System Upgrade.....	54
5.6.4 Version Information.....	55
5.6.5 System Log.....	55
5.6.6 Online Users.....	56
6. Playback.....	56
6.1 Play SD Card Videos/Images.....	56
6.1.1 SD card video playback:.....	57
6.1.2 SD card image playback:.....	59

6.2 Play Local Videos/Images.....61

1. Camera Login

After the camera is connected to the network, the user can enter the camera's IP address in the browser address bar to access the camera.



Figure 1.1 Camera Login Interface

The specific login steps are as follows:

1. Enable the browser. (Note: only Google, Edge and Firefox are supported.)
2. Enter the IP address of the dual-spectral camera in the browser address bar: `http://xx.xx.xx.xx`. For example, enter `http://192.168.1.123`. Enter the *Login* interface, as shown above.
3. Enter the correct user name and password (the default user name and password of the camera is admin/admin).
4. The password is forced to be changed during the first login and factory default restoring.
5. Enter the new password, and click the *Login* icon to enter the home page of the camera, otherwise a related login error will be prompted.

2. Preview

The preview screen has two channels for simultaneous monitoring, one for visible light and the other for thermal imaging as shown below.




Figure 2.1 Preview Interface

Snap

After selecting the visible light or thermal imaging channel with the mouse, click the *snap* icon in the lower right corner, the real-time picture of the selected channel will be captured. The captured pictures can be viewed in the browser download folder by default.


Video

After selecting the visible light or thermal imaging channel with the mouse, click the *video* icon in the lower right corner to start recording, and click the icon again to end the recording. The videos can be viewed in the browser download folder by default.

All Video

Click the *all video* icon in the lower right corner to start the dual channel video recording, and click the icon again to end the video recording. By default, you can view all videos in the browser download folder.

Talk 

The external interface of the camera *line out* is connected to the speaker, *line in* is connected to the audio source (pickup or phone player) and the talk function is enabled by clicking the icon  in the lower right corner of the web preview interface. Use the headset to speak on the computer, and the sound can be heard from the speaker. The sound of the audio source through *line in* can be heard in the headset.


Note: You need to enable *Insecure origins treated as secure* first before *using* the talk and voice function. Click the *Relaunch* icon, and the microphone can be used in the webpage by typing in `http://xx.xx.xx.xx` in the address bar after rebooting the browser.

The option can be enabled by typing in the following address in the browser.

Chrome: `chrome://flags/#unsafely-treat-insecure-origin-as-secure`

Edge: `edge://flags/#unsafely-treat-insecure-origin-as-secure`

Voice: 

The external interface of the camera *line in* is connected to the audio source (pickup or phone player), turn on the voice switch  in the lower right corner of the preview interface, and the sound can be heard on the computer web terminal.

Play/Pause: 

Click the *play/pause* icon at the bottom of the video, and the two channels of visible light and thermal imaging will be frozen at the same time. Click the *play/pause* icon again and the two channels will return to normal.

Note: the images in the two channels will be automatically displayed by default after the camera is turned on.

3. Temperature Measurement

3.1 Basic Parameters

Thermometry: enable the *thermometry* or not. The point, line and area can be drawn only after the thermometry function is enabled.

Temperature Rate: setting range is 1-12, 12 by default.

Temperature Unit: *Celsius Degree*, *Fahrenheit*, and *Kelvin* are interchangeable.

Temperature Gear: *high gain* and *low gain*, high gain by default.

Temperature Stack: *Before Stacking*, and *After the Superposition* can be set. *After the superposition* by default.

■ *before stacking*: Temperature data is added to the stream and can be displayed during playback.

■ *after the superposition*: temperature data is not added to the stream. In order to see the temperature data, the intelligent information overlay should be enabled when the video is played back.




Figure 3.1 Temperature Measurement- Interface of Basic Parameter Settings

Environmental Parameters:

Set the environmental variables of the thermal imaging channel, including emissivity/reflected temperature/atmospheric temperature/atmospheric transmissivity/distance as shown in the below figure.

The screenshot shows a mobile application interface titled "Environmental Parameters". It features five input fields with the following values: Emissivity (1), Refl. temp (25), Atmospheric T (25), Atmospheric transmittance (1), and Distance (0.5). At the bottom of the interface, there are three buttons labeled "Read", "Set", and "Reset".

Figure 3.2 Temperature-Environmental Parameters Interface

Note: all the environmental parameters are set according to these values by default, and the info can also be set separately in alarm rules.

3.2 Cold Hot Tracking

After the *High Temperature Alarm/Low Temperature Alarm* is enabled, the highest/lowest of the whole frame reaches the set alarm threshold, and the system will make alarm calls and alarm linkage actions.

Procedures: refer to Table 3-1 for detailed parameters.

- 1) *Startup* on the *Cold Hot Tracking* interface.
- 2) Enable *High Temperature Alarm/Low Temperature Alarm*. Set the alarm temperature threshold.
- 3) Set the *filtering time* as M seconds.
- 4) Set the *Tolerance of Temperature* as N.

- 5) Set the alarm linkage parameters: the corresponding event is linked when the alarm is triggered, for example, *Record* (enable visible/thermal channel), *Take Pictures*, *E-mail* linkage, *Flash Alarm*, *Voice Alarm* and *Alarm Output*, etc.
- 6) Click *save* to finish. See the following figure.

Cold Hot Tracking

Start Up

High Temperature Alarm 40 °C

Low Temperature Alarm 40 °C

Filtering Time 5 秒

Tolerance Of Temperature 3 °C

Linkage Way

Record 01 02

Video Delay 10 秒(10~300)

Alarm Output 01

Alarm Delay 10 秒(10~300)

Take Pictures 01 02

Flash Alarm

Residence Time 5 秒(5~30)

Voice Alarm

File alarm.wav

Times Of Play 5 (1~15)

E-mail

Refresh Save

Figure 3.3 Temperature-Cold Hot Tracking Interface

Parameter	Descriptions
1 Enable	To make the alarm linkage rules take effect
2 High Temp Alarm	threshold of high temperature alarm
3 Low Temp Alarm	threshold of low temperature alarm
4 Filtering Time	Alarm conditions: reach the temperature threshold and meet the time period requirement e.g. the filtering time is set as 3s, then while the temperature threshold reaches and lasts for 3s, the alarm will be triggered.
5 Tolerance of Temperature	A tolerant alarm temperature range needs to be set in case of drifting temperature. e.g. the tolerance of temperature is set as 3°C, the alarm temperature is set as 45°C, then the alarm will be triggered when the detected temperature reaches 45°C, and the alarm will stop until the temperature is below 42°C.
6 Record	<i>Record</i> : select this option and set the channel and the alarm will be automatically triggered in the selected channel. 01 stands for the visible channel, 02 stands for the thermal channel. <i>Video Delay</i> : type in the delay time. After the alarm is finished, the alarm video would stop after a while.
7 Alarm Output	<i>Alarm Output</i> : the alarm output will be enabled after this option is selected. When the alarm is triggered, the system will link the alarm output and make alarms. <i>Alarm Delay</i> : type in delay time. After the alarm is finished, the alarm video would stop after a while. Before the function is enabled, please make sure that the alarm device is connected.(e.g. alarm light and alarm whistle)
8 Take Pictures	Select this option and set the channel, and the image will automatically

	<p>captured in the selected channel when the alarm is triggered.</p> <p>01 stands for visible channel,02 stands for thermal channel.</p>
9 Flash Alarm	<p>The filling light of the camera will flash when the alarm is triggered after this option is selected.</p> <p>Residence Time: set the flashing time, 5s by default.</p>
10 Voice Alarm	<p>The system will link to broadcast audio files when the alarm is triggered after this option is selected.</p> <p>File:select the built-in audio alarm files.</p> <p>The audio files can be uploaded by the user, refer to chapter 5.1.3 for detailed operation.</p> <p>Times of Play: set the times of broadcasting.</p>
11 E-mail	<p>Select this option, the system will send Email to inform the user when the alarm is triggered.</p> <p>The Email address should be set before this function is enabled, refer to chapter 5.2.3 SMTP for detailed operation.</p>
12 Deployment time	<p>You can set six time ranges every day in a week to enable the planned time range, accurate to the second. You can also replicate the same time range. When an alarm occurs within the set time range, related alarm actions will be linked. The full time period is enabled by default.</p>

Table 3-1 Alarm Rule Parameters

3.3 Thermography Analysis

3.3.1 Measurement List

The measurement data list can be displayed after *Thermometry* is enabled. See the following picture:




Figure 3.4 Measurement Analysis-Data List Interface

The measurement data is displayed in group: temp points (P1~P8), temp lines list(L1~L8), temp areas (R1~R8) and shielded areas(SR1~SR12), maximum 8 articles of records for each group.

Alarm Rules Settings

Select an article of data among temperature measurement list. See the following figure:






Figure 3.5 Thermography Analysis-Alarm Rules Setting Interface

The environmental parameters and alarm rules can be set separately. See the following figure for environmental parameter settings.




Parameter	Value
Environmental Parameters	<input checked="" type="checkbox"/>
Emissivity	1
Refl. temp	25
Atmospheric T	25
Atmospheric transmittance	1
Distance	0.5

Figure3.6 Thermography Analysis-Environmental Parameters Settings Interface

The environmental parameters can be set only after environmental parameters is enabled  . If the environmental parameters function is enabled and set here, then the environmental parameters should be followed, or else the parameters in *Basic Parameter* should be followed. (Refer to the environmental parameters in chapter 3.1 for basic parameters settings.)

Refer to chapter 3.2 *Cold Hot Tracking* for settings of alarm rules and linkage way.



Alarm Set

Alarm Rule: none

The Alarm Threshold: 40 °C

Filtering Time: 5 S

Tolerance Of Temperature: 3 °C

Linkage Way

Record 01 02
 Video Delay: 10 S (10~300)

Alarm Output 01
 Alarm Delay: 10 S (10~300)

Take Pictures 01 02

Flash Alarm
 Residence Time: 10 S (5~30)

Voice Alarm
 File: alarm.wav

Times Of Play: 5 (1~15)

E-mail

Figure 3.7 Thermography Analysis-Alarm Rules Interface

Confirm to delete 

The info of drawn points, lines, rectangular and shielding areas are displayed in the measurement lists, which can be ticked and deleted.

Check all 

The drawn measurement info can be checked all or not checked.

3.3.2 Temperature Measurement Drawing

Point/line/region Drawing 

Click the icon point/line/region to draw the corresponding temperature measurement graph in the video screen (drawing up to 8 points/line/rectangular respectively, and 24 graphs at the same time). The temperature of the point will be displayed in real time, and the line/region will display 3 temperatures in real time (the highest /lowest temperature/average temperature).

Shielding Area: 

Click the *Shielding Area* icon to draw the shielded area on the video screen (up to 12 shielded areas), and the temperature data will not be displayed in the shielded area.

Display Temperature Bar: 

Click the icon to turn on/off temperature bar, when turned on, the temperature bar including the highest and lowest temperature value will be displayed on the right side of the temperature measurement interface. When turned off, the bar will be hidden.

Color Palette: 

20 palettes are supported as below.



Figure 3.8 Thermography Analysis -Palette

Temperature Difference: 


Compare the drawn several regions, and the comparison rules can be added. The comparison result can be regarded as the alarm trigger. Four articles of rules can be output at most.

Regional Temperature Comparison

<input type="checkbox"/>		And		None	0.2	°C Alarm Output	<input type="checkbox"/>	01	<input type="button" value="Clear"/>
<input type="checkbox"/>		And		None	0.2	°C Alarm Output	<input type="checkbox"/>	01	<input type="button" value="Clear"/>
<input type="checkbox"/>		And		None	0.2	°C Alarm Output	<input type="checkbox"/>	01	<input type="button" value="Clear"/>
<input type="checkbox"/>		And		None	0.2	°C Alarm Output	<input type="checkbox"/>	01	<input type="button" value="Clear"/>

Figure 3.9 T Thermography Analysis -Temperature Difference Set Interface

Delete: 

Click the *Delete* icon  in the lower right corner of the temperature measurement interface, and click the point/line/rectangle/shielding area in the screen to delete it (the corresponding data in the temperature measurement list will also disappear after deletion).

Note: The functions of delete/point/line/ rectangle/shielding area are mutually exclusive, and any two of them cannot be turned on at the same time.

4. Smart Analysis

4.1 General Behavior Analysis

4.1.1 Trip Wires Intrusion

When the target moves across the cordon in the set direction, the system will generate an alarm and linkage setting action.

This function is only available in thermal channel.

Setting Steps:

1. Select channel: *Smart-Trip Wires Invasion-Channel 2*.
2. Enable: enable/disable this function.
3. Click + in the upper right corner to add a new rule (up to 8 articles of rules can be added, and the parameter settings between different rules are completely independent), and set the rule name.
4. Click *Drawing Rules* to draw a rule on the monitoring screen, click *Remove* to delete the current rule, and click *Drawing Rules* again to draw the rule line.
5. Direction: set the direction of tripwire intrusion, optional A->B, B->A, A<->B.
6. Set alarm linkage parameters: when an alarm is triggered, the corresponding actions will be linked.
7. Deploying time: set the time period for triggering the tripwire intrusion event.
8. Click *Confirm* to complete the setting. See below:




Figure 4.1 Trip Wires Intrusion Setting Interface

4.1.2 Region Intrusion

When the target crosses the region (*Enter/Leave/Pass In and Out*), the system generates an alarm and linkage setting action.

This function is only available in thermal channel.

Setting Steps:

1. Select channel: Smart-Region Invasion-Channel 2.
2. Enable: enable/disable the function.
3. Click + in the upper right corner to add a new rule (up to 8 rules can be added, and the parameter settings between different rules are completely independent), and set the rule name.
4. Click *Drawing Rules* to draw the rule on the monitoring screen, click *Remove* to delete the current rule, and click *Drawing Rules* again to draw the rule line.
5. Direction: set the direction of regional intrusion, optional *Enter/Leave/Pass In and Out*.
 - When *Enter* is selected, an alarm will be triggered when the target enters the area.
 - When *Leave* is selected, an alarm will be triggered when the target leaves the area.

- When selecting *Pass In and Out.*, an alarm will be triggered when the target enters or leaves the area.
- 6. Set alarm linkage parameters: when an alarm is triggered, the corresponding actions will be linked.
- 7. Deploying time: set the time period for triggering the tripwire intrusion event (default setting is all time).
- 8. Click *Confirm* to complete the setting. See below:




Figure 4.2 Region Intrusion Setting Interface

Environment setup recommendations:

- The required distance between the target and the camera:

Depending on the focal length, installing height and angle, about more than 2-3 meters.

- Target Size Requirement:

Max.: the width should be shorter than 1/2 of the image width, the height should be shorter than the height of the image.

Min.: the width or height should be longer than the 1/16 of the image width or height.

4.1.3 Global Config

Set the maximum and minimum value of the target filtering size, the alarm will be triggered only when the target size is within the two filtering boxes.

Note: the maximum size by default is 8191*8191, the minimum size is 500*500, the size value uses the 8192 unified coordinate system within the internal program. For example, the resolution is **1920*1080**, then the actual size of 500*500 is **【500*(1920/8192)】 * 【500*(1080/8192)】**)

Setting Steps:

- 1) Select channel: Smart-Global config-Channel 2;
- 2) Select the maximum or minimum size, click *Draw the Target*, and you can draw a filtering box in the video image by dragging the mouse. (The alarm will be triggered only when the target size is within the two filtering boxes).
- 3) Select the maximum and minimum size, click *remove* to delete the corresponding filtering box(The default filtering box will be displayed after deletion).
- 4) Click *Draw the Target* again to draw another filtering box.
- 5) Click *Confirm*, as shown in the following figure:




Figure 4.3 Global Config Setting Interface

4.2 Fire Warning

4.2.1 Fire Alarm

Set fire alarm rules. When it is judged as a fire by the system, an alarm and linkage setting action will be generated.

This function is only available in thermal channel.

Setting Steps:

1. Enable: enable or disable fire alarm.
2. Select the fire alarm mode according to actual needs: *Anti-interference* or *High Response* modes. *Anti-interference* mode by default.
3. Area: at most four fire detecting areas can be set at the same time. The area color, area name, threshold and alarm rules can be set separately for each area.
4. Draw Area: click *Drawing Rules*, then you can draw the fire detecting areas. Different color indicates different detection area.
5. Remove: click *Remove* icon, the drawn area will be removed. Click *Drawing Rules* again to draw other detection areas.
6. Sensitivity: the greater the value, the more easily to detect the fire, 50 by default.
7. Set the alarm linkage parameters and the corresponding actions will be linked when the alarm is triggered.
8. Set deploying time: the alarm events will be triggered only within the time range.
9. Click *Confirm* to complete the setting.




Figure 4.4 Fire Alarm Setting

4.3 Alarm Input

When an external alarm input generates an alarm, the system will generate an alarm and linkage setting action.

Setting Steps:

1. Enable: Enable or disable the alarm input;
2. Alarm input: the device supports 1 channel alarm input and 1 channel alarm output.
3. Debouncing: setting range is 0-100s, and only one alarm event is recorded in the debouncing time period.
4. Sensor type: select *normally open* or *normally closed* according to the type of external alarm device sensor.
5. Alarm Linkage: set alarm linkage parameters and the corresponding actions will be linked when the alarm is triggered.
6. Deploying time: the alarm events will be triggered only within the set time range.
7. Click *Confirm* to complete the setting.




Figure 4.5 Alarm Input Setting

4.4 Burning Alarm

The strong light protection function will be enabled when the sun directly shines on the camera and the energy value reaches the threshold, the infrared lens shutter will be shut automatically and the linkage alarm will be triggered.

Note: the video stream on the thermal channel is frozen, the switch can be disabled manually to cancel the strong light protection, then the video stream will return to normal.

Setting Steps:

- 1) Enable the function.
- 2) Energy value: 0-100, the smaller energy value will trigger the alarm more easily.
- 3) Sensitivity: 0-100, the higher sensitivity will trigger the alarm more easily.
- 4) Alarm linkage: set the alarm linkage parameters, then the corresponding events will be linked when the alarm is triggered.
- 5) Deploying time: the alarm events will be triggered only within the time range.
- 6) Set *Confirm* to finish.




Figure4.6 Burning Alarm Set Interface

4.5 Exception Handling

4.5.1 SD Card Exception

When there is some exception in SD card, the system will generate an alarm and linkage setting action. SD card abnormalities include not existing or SD card error.

4.5.2 Network Anomaly

When the network is abnormal, the system will generate an alarm and linkage setting action. Network abnormalities include network disconnection and IP conflicts.

4.5.3 Illegal Access

When the number of login password errors exceeds 5 times or IP access is not on the white list, the system will generate an alarm and linkage setting action.

5. Settings

5.1 Camera Settings

5.1.1 Camera Parameters

Camera parameters can be set for both visible light and thermal imaging.

Channel 1--Visible Light

■Image Parameters Setting

Brightness: adjust the overall brightness of the image by linear adjustment, keep the default value, the larger the value, the brighter the image, and vice versa.

Contrast: The larger the value, the greater the brightness and contrast of the image, and vice versa; when the value is set too large, the dark areas of the image are too dark, and the bright areas are easy to overexpose. If the setting is too small, the image will be blurred.

Saturation: the larger the value, the brighter the image color; the smaller the value, the lighter the image color.

Acuity: adjust the sharpness of the image edge. The larger the value, the more obvious the image edge; when the value is larger, the image is prone to noise.

Style: *Standard, Soft, Gorgeous* can be selected.

■ **Standard:** the overall color of the image is neutral, not dark or light.

■ **Soft:** the overall color of the image is soft and light.

■ **Gorgeous:** the overall color of the image is brighter and darker.

Flip: there are three modes to be selected.

Upside Down: the image will flip 180° up down.

Flip Horizontal: the image will flip 180° from left to right.

Normal: the image returns to normal state.




Figure 5.1 Camera Parameters Setting

■ Exposure Parameters Setting

FLK: outdoor/50Hz/60Hz can be selected.

50Hz: auto/manual adjust exposure, and make sure there is no cross stripe on the image.

60Hz: auto/manual adjust exposure, and make sure there is no cross stripe on the image.

Outdoor: manual switch exposure mode to achieve the corresponding effect.

Mode: *Auto/Manual* can be selected. Exposure time and gain can be set in manual mode to achieve image display brightness.

Exposure Strategy: *None/Strong Inhibition/Backlight Compensation* can be selected.

None: the backlight mode is disabled.

Strong Inhibition: weaken the strong light part and brighten the dark area to achieve the light balance of the whole picture.

Backlight Compensation: solve the problem of darkening of foreground objects due to underexposure.

See the following figure.




Figure 5.2 Exposure Setting

■ Day and Night Conversion

Day Night Mode: *Colour/Black and White/Time Period* can be selected.

Colour: the system will be forced to switch to day mode.

Black and White: the system will be forced to switch to night mode.

Time Period: you can customize the time period during day or night, and switch the corresponding day and night mode.

Delay: delay setting is supported in automatic mode. The delay time will be set within the range 2-10s.




Figure 5.3 Day and Night Conversion

Thermal Imaging Channel

■ Image Adjust

Brightness, Contrast, Upside Down, Flip Horizontal: refer to the descriptions of visible channel for detailed information.

Background Correction: the image is optimized according to the current scene background.

Shutter Correction: the image is optimized through shutter adjustment.

DDE Status

2D Noise Reduction: remove the spatial noise of the image. The larger the value is, the less the image noise is, but the more blurred the image details are;

3D Noise Reduction: remove the 3D noise of the image, and keep the default value. The larger the value is, the better the noise reduction effect, to ensure stable image output, but the image tail of the moving objects more serious.

Detail Enhancer: enhance the image detail manually, the higher the level, the better the detail, but the bigger the noise;

Video Enhancer: select the ROI or important parts of the image, set the video quality enhancement area, the image of the selected area is more bright and clearer. You can choose 25% center point, 50% center point, 75% center point, full screen, bottom, middle, top and custom, corresponding to different positions and ranges in the screen.

Select *Customization*, click *Draw*, and then hold the left button on the screen and drag to add the video quality enhancement box. After selecting the corresponding region option, an orange box marks the selected region in the left preview screen.

Pseudo Color: there are 20 types: white hot, black hot, rainbow, HC rainbow, Iron, Lava, Sky, MidGrey, RdGy, PuOr, Special, Red, IceFire, GreenRed, Special 2, RedHot, Greenhot, Bluehot, Green, Blue.

Merge: overlay the visible channel data with the thermal channel data, retain the gray information of visible image and mark different temperatures with different color palettes to make the video image of thermal channel clearer.

Refer to the following figure for the image fusion parameters.

Image Fusion Ratio: 0 stands for visual image, 100 stands for thermal image, 50 stands for the default dual-spectrum overlay effect.

Edge Fusion Ratio: 0 stands for no edge fusion, 100 stands for highlighted edge fusion, 50 stands for the default dual-spectrum edge fusion.

Horizontal: change the horizontal parameters, align the visual image with the thermal image in horizontal.

Vertical: change the vertical parameters, align the visual image with the thermal image in vertical.




Figure 5.4 Merge Settings Interface of Thermal Channel

5.1.2 Video

5.1.2.1 Video Stream

Visible Light

Main Stream

■Encoding Scheme:

H.264: main Profile encoding.

H.265: High Efficiency Video Coding. Higher-quality network videos can be transmitted under limited bandwidth, and videos of the same quality can be played with only half of the original bandwidth.

■Resolution: there are four types for the resolution of the video: 1280*720(720p), 1920*1080(1080P), 2592*1944, 2560*1440.

■Video Frame Rate: the number of frames a video contains per second; the higher the frame rate, the more realistic and smooth the image.

Note: P system supports up to 25 frames, N system supports up to 30 frames.

■Stream Control: CBR is a fixed stream, and VBR is a variable stream. The image quality can only be set in the variable stream mode, not in the fixed stream mode.

FixQp fixes the Qp value. During the bit rate statistics time, all macroblocks in the encoded image have the same Qp value. Using the image QP value set by the user, and the QP values of I frame and P frame can be set respectively.

■Image Quality: the picture quality can be set only in VBR mode, and six levels of 1-6 can be set, the higher the level, the better the picture effect, the larger the code stream, but it will not exceed the stream limit.

■Stream Limit: in variable stream mode, this value is the upper limit of code stream; while in fixed stream mode, this is a fixed value.

■Frame Spacing: the number of P frames between two I frames ranges from the size of the set frame rate to the maximum value of 150. It is recommended to set it to 2 times the frame rate.

Auxiliary Stream

■Encoding Scheme:

H.264: Main Profile encoding scheme.

H.265: High Efficiency Video Coding. Higher-quality network videos can be transmitted under limited bandwidth, and videos of the same quality can be played with only half of the original bandwidth.

■Resolution: there are three types for the resolution of the video 640*480(VGA)/704*576(D1)/352*288(CIF).

■Video Frame Rate: the number of frames a video contains per second; the higher the frame rate, the more realistic and smooth the image.

Note: P system supports up to 25 frames, N system supports up to 30 frames.

■Stream Control: CBR is a fixed stream, and VBR is a variable stream. The image quality can only be set in the variable stream mode, not in the fixed stream mode.

■Image Quality: the picture quality can be set only in VBR mode, and six levels of 1-6 can be set, the higher the level, the better the picture effect, the larger the code stream, but it will not exceed the stream limit.

■Stream Limit: in variable stream mode, this value is the upper limit of code stream. While in fixed stream mode, this value is a fixed value.

■Frame Spacing: the number of P frames between two I frames, ranges from the size of the set frame rate to the maximum value of 150. It is recommended to set it to 2 times the frame rate.

Note: the parameter settings of main stream and auxiliary stream for thermal imaging is basically the same with visible light, except the resolution supported and the reference stream code value.

Video Stream | Image Stream | Video Overlap | Area-Of-Interest

Channel Switch channel 01 channel 02

Main Stream	Auxiliary Stream
Encoding Scheme: H264	Encoding Scheme: H264
Resolution: 1920*1080(1080P)	Resolution: 704*576(D1)
Video Frame Rate: 25	Video Frame Rate: 25
Encode Control: VBR	Encode Control: FIXQP
Image Quality: 3	Image Quality: 5
Reference Stream: 2048~8192Kb/s	Reference Stream: 512~2048Kb/s
Stream Limit: 3072	Stream Limit: 2048
Frame Spacing: 66 (25~150)	Frame Spacing: 50 (25~150)

Default Refresh Confirm

Figure 5.5 Video Stream Settings of Visible Channel

Video Stream | Image Stream | Video Overlap | Area-Of-Interest

Channel Switch channel 01 channel 02

Main Stream	Auxiliary Stream
Encoding Scheme: H264	Encoding Scheme: H264
Resolution: 1280*960(960P)	Resolution: 640*480(VGA)
Video Frame Rate: 25	Video Frame Rate: 25
Encode Control: CBR	Encode Control: CBR
Image Quality: 3	Image Quality: 3
Reference Stream: 1280~5120Kb/s	Reference Stream: 384~1536Kb/s
Stream Limit: 3072	Stream Limit: Customizations
Frame Spacing: 50 (25~150)	Frame Spacing: 2048 (Kb/S)
	Frame Spacing: 50 (25~150)

Default Refresh Confirm

Figure 5.6 Video Stream Settings of Thermal Channel

5.1.2.2 Image Stream

Visible Channel

- **Image Size:** The size of the captured image is consistent with the set resolution.
- **Image Quality:** You can choose the 6 levels of image quality as best (6), better (5), good (4), poor (3), worse (2), and worst (1).
- **Capture Interval:** the rate of capture.

Note: The image stream setting of thermal imaging channel(channel 02) is similar to that of the visible channel.

Video Stream **Image Stream** Video Overlap Area-Of-Interest

Channel Switch channel 01 channel 02

Image Size 640*480(VGA) ▾

Image Quality 3 ▾

Capture Interval 1Seconds/Sheet ▾

Default Refresh Confirm

Figure 5.7 Image Stream Settings of Visible Channel

Video Stream **Image Stream** Video Overlap Area-Of-Interest

Channel Switch channel 01 channel 02

Image Size 640*480(VGA) ▾

Image Quality 3 ▾

Capture Interval 1Seconds/Sheet ▾

Default Refresh Confirm

Figure 5.8 Image Stream Settings of Thermal Channel

5.1.2.3 Video Overlap

Visible Channel

■ **Regional Coverage:** When you need to protect the privacy of certain areas on the video screen, you can set regional coverage.

Steps:

1. Enable: enable or disable the *regional coverage*.
2. Click *Draw Area* to draw a rectangular frame at the privacy position that needs to be blocked in the video screen (supporting up to 4 privacy blocking areas). Click *Delete*, and select the area frame to delete the corresponding area frame; Click *Draw Area* to draw the privacy blocking area again.
3. Click *Confirm* to complete the setting.

The **regional coverage setting for thermal imaging channel is similar to that of visible light channel.**




Figure 5.9 Regional Coverage Settings

■ **Channel Title:** you can set the channel title when you need to display the channel title in the video screen.

Steps:

1. Enable: enable or disable the channel title.
2. Enter the channel title to be set in the channel title input box.
3. Drag the channel title frame with the mouse to adjust the position of the channel title in the video screen.
4. Set the font color.
5. Click *Confirm* to complete the setting.

The channel title setting of the thermal imaging channel is similar to that of the visible light channel.




Figure 5.10 Video Overlap—Channel Title Settings

■ **Custom Title:** you can set the custom title when you need to display multiple lines of custom titles in the video screen.

Steps:

1. Enable: enable or disable the custom title.
2. Enter the content of multiple lines of custom title in the custom title input box (up to 4 lines of input are supported).
3. Drag the custom title area frame with the mouse to adjust the position of the custom title in the video screen.
4. Set the font color.
5. Click *Confirm* to complete the setting.

The custom title setting of the thermal imaging channel is similar to that of the visible light channel.




Figure 5.11 Video Overlap—Custom Title Settings

■ **Time Title:** you can set the time title when you need to display time title in the video screen.

Steps:

1. Enable: enable or disable the time title.
2. Drag the time title area frame with the mouse to adjust the position of the time title in the video screen.
3. Set the font color.
4. Click *Confirm* to complete the setting.

The time title setting of the thermal imaging channel is similar to that of the visible light channel.




Figure 5.12 Video Overlap—Time Title Settings

5.1.2.4 Region of Interest

Set the region of interest in the screen, and the area of interest will be displayed according to the set image quality.

Steps:

1. Enable: enable or disable the region of interest.
2. Click *Draw Area* to draw the region of interest on the video screen (up to 1 areas can be set), and set the image quality of the corresponding area of interest. Click *Delete* to delete the selected area. Click *Draw Are* to draw the area of interest again.
3. Click *Confirm* to complete the setting.

The region of interest setting of thermal imaging channel is similar to that of visible light channel.




Figure 5.13 Region of Interest Setting

5.1.3 Audio

5.1.3.1 Audio

Coding

Enable: enable or disable this function, the audio can be enabled only when the video is enabled;

Encoding Scheme: the encoding scheme of the audio, which contains PCM, G.711A, G.711U and AAC, the set audio encoding scheme will make audio and voice intercom take effect at the same time.

Sampling Rate: the audio sampling frequency

Attribute

Audio Input Type: support Line-in only.

Mic Volume: adjust the mic volume.

Speaker Volume: adjust the speaker volume.





Figure 5.14 Audio Setting Interface

5.1.3.2 Alarm Audio

there is a default alarm audio(alarm.wav) on the interface, and the user can upload the alarm audio, which needs to meet the audio file requirements: sampling rate 16k, sampling accuracy 16bit, encoding type (PCM/G711A/G711U), the files can be downloaded, deleted and the file name can be revised.

See the following figure:



The screenshot displays the 'Alarm Audio' setting interface. It features a table with columns for Name, Size(M), Play, Download, Edit, and Delete. Below the table is an 'Add Audio File' button and a note about audio file requirements.

Name	Size(M)	Play	Download	Edit	Delete
English_woman_no_mask.wav	0.06	▶	↓	✎	⊖
English_woman_temperature_too_high.wav	0.08	▶	↓	✎	⊖
alarm.wav	0.06	▶	↓	✎	⊖

[Add Audio File](#)

Upload audio file requirements: sampling rate 16K, sampling accuracy 16bit, encoding (PCM/g711a/g711u) wav format audio file!

Figure 5.15 Alarm Audio Setting Interface

5.2 Network Settings

5.2.1 TCP/IP

Set the IP address and DNS server of the camera to ensure that it can communicate with other devices in the network. See below:

TCP/IP

Host Name

DHCP

* MAC Address

* IP Address

* Subnet Mask

* Default Gateway

* Preferred DNS

* Standby DNS

Figure 5.16 Network Settings—TCP/IP Setting

Other parameters:

- DHCP: 1. when not enabled, it is in static mode. You can manually set the IP address, subnet mask, and gateway.
2. When enabled, the device will automatically obtain an IP address (there is a router with DHCP enabled in the network connected to the device); at this time, the *IP address*, *Subnet Mask* and *Default Gateway* cannot be set.
- MAC address: display the MAC address of the host, which cannot be changed.
- IP address/Subnet Mask/Default gateway: input the correct *IP address*, *Subnet Mask* and *Default Gateway* according to the actual situation; the IP address and default gateway must be in the same network segment and matched with the subnet code.
- Preferred DNS server: DNS server IP address.
- Alternative DNS server: alternative IP address of DNS servers.

5.2.2 DDNS

By setting the DDNS parameters, the system can dynamically update the relationship between the domain name and IP address on the DNS server when the device's IP address frequently changes, and you can directly use the domain name to remotely access the device without recording the constantly changing IP address.

Server Type: supports 4 types (oray DDNS, NO-IP DDNS, Dynans DDNS, pubyun DDNS).

Server Address: each server type has a corresponding address.

Domain: the domain name registered by the user on the website of the DDNS server provider.

Port: the port can be customized.

Username/Password: enter the username and password obtained from the DDNS service provider; users need to register an account (including username and password) on the DDNS server provider website.




Figure 5.17 Network Settings-DDNS Setting

5.2.3 SMTP

Set the mailbox information. After enabling the mail function of the alarm linkage, the system will send an alarm email to the designated recipient when an alarm is triggered.

SMTP Server: different mailbox types have different server addresses. For example, (163 mailbox server address: smtp.163.com/Sina mailbox server address: smtp.sina.com, etc.).

Port: the port is related to the encryption method (the port for SSL encryption is generally 465, and the port for TLS or non-encryption is generally 25).

Username/Password/Sender: fill in the sender's mailbox information according to the actual situation.

Encryption: three options of *None/SSL/TLS*.

Theme: email subject information.

Recipient: recipient's email address.

The image shows a dark-themed web interface for configuring SMTP settings. The title is "SMTP". The settings are organized into two main sections. The first section includes: "SMTP Server" (input field with "none"), "Port" (input field with "25"), "Username" (input field with "anonymity"), "Password" (input field with "****" and a visibility icon), and "Sender" (input field with "none"). The second section includes: "Encryption" (dropdown menu with "None" selected), "Theme" (input field with "Message"), and "Recipient" (a list of email addresses with "+" and "-" buttons). At the bottom of the interface are four buttons: "Test", "Default", "Refresh", and "Confirm".

Figure 5.18 Network Settings-SMTP Setting

5.2.4 UPnP

Establish a mapping relationship between the private network and the external network through the UPnP protocol, and users of the external network can access the internal network device by accessing the external network IP address.

Prerequisites:

1. Make sure that the PC has installed the UPnP network service.
2. Log in to the router and set the router's WAN port IP address to access the external network.
3. The router enables the UPnP function.
4. Connect the device to the router's LAN port and access the private network.
5. Set the *IP address* of the device to the private network IP of the router, or select *DHCP* to obtain an IP address automatically.

Steps:

1. Enable the UPnP interface.
2. Select the port mapping method and the corresponding service name.
3. UPnP is divided into two mapping modes.
 - *Customization* mode: users can modify the external port.
 - *Default* mode: users do not need to change the mapping and port.
4. Click *Confirm* to complete the setting.

Enter ***http://external network IP: external port number*** in the browser to access the private network device with the corresponding port number in the router.




Figure 5.19 Network Settings-UPnP Setting

5.2.5 FTP




Figure 5.20 Network Settings-FTP Setting

1. FTP is enabled;
2. Set the FTP address (e.g. 10.10.18.160), port number (e.g. 21), user name, password, etc., and perform network tests on the FTP.

3. Storage Directory: the location of the server where the snapshots are stored. (See Note 5)

Default directory: the default directory when configuring the server;

Custom directory: set a custom remote server storage directory.

4. Click *Confirm* to complete the setting.

5. This setting can be used to save the captured pictures in the corresponding FTP designated directory in the *Capture Plan*.

Go to *Settings*→*Storage Management*→*Capture Plan*→*Storage*→Select *Upload FTP* and click *Confirm*, as shown in the figure below:

The schedule is mainly to facilitate the one click synchronization of the time period set in the general schedule when setting the deployment time and video recording / capture plan. The general schedule can be edited (drag and click operation) or reset with one click.




Figure 5.21 Capture Plan-Upload FTP Setting

5.2.6 Platform

The device supports access to other devices or servers that comply with the national standard 28181 protocol, and realizes some related real-time monitoring, alarm control and other functions.

Steps:

1. Enable the platform access;
2. Set the parameters of the national standard 28181. Generally, only the two parameters of SIP server IP and device number need to be set, and the other parameters are consistent with the docking device or server.

Note: Please set the parameters in accordance with the information provided by the platform during actual use. All parameters must be set correctly, otherwise there may be exceptions such as device registration failure and no response of functions.

3. Click *Confirm* to complete the setting.

GB28181

Enable

SIP Server Number	34020000002000000001	SIP Domain	3402000000
SIP Server IP	192.168.1.198	SIP Server Port	5060
Equipment Number	34020000001180000001	Login Password	***** <input type="checkbox"/>
Local SIP Port	5060	Validity Of Registration	3600
The Heartbeat Cycle	60	Expired Times	3
Area Number	340200	Access Module Code	000001019
Channel Information	Channel 1		
Channel Number	34020000001310000001	Alarm Level	1
Alarm Related	Channel 1		
Information			
Channel Number	34020000001340000001	Alarm Level	1

Default Refresh Confirm

Figure 5.22 Network Settings-Platform Setting

5.3 Peripherals Settings

5.3.1 Filling Light

The fill light has two modes: automatic and manual.

Automatic Mode: adjust the illuminance of filling lamp according to the visual scenes.

When the illuminance of visible light channel is lower than a certain value, the screen will automatically switch to black and white. The infrared light is on, the darker the picture, the brighter the infrared light.

When the illuminance of visible light channel is higher than a certain value, the screen will automatically switch to color and the infrared light will go out.

Manual Mode: enable or disable the infrared light.




Figure 5.23 Peripherals Settings-Fill Light Setting

5.4 Storage Management

5.4.1 Storage Device

Display the relevant information of the local SD card, for example, device name, status and used space etc. The SD card can also be formatted.





Figure 5.24 Storage Management-Storage Device

5.4.2 Video Control

Video Duration: the duration of each video file.

Pre-recording Time: when an alarm is triggered, the time of recording is advanced. For example, when 5 is input, the system saves the recording 5 seconds before the alarm occurs to the recording file.

Video Stream: including the main stream and the auxiliary stream.



The screenshot shows a 'Video Control' panel with three main settings:

- Video Duration:** A dropdown menu set to '30' with 'Minutes' as the unit.
- Pre-Recording Time:** A text input field set to '5' with 'S' as the unit.
- Video Stream:** A dropdown menu set to 'Main Stream'.

At the bottom of the panel are three buttons: 'Default', 'Refresh', and 'Confirm'.

Figure 5.25 Storage Management-Video Control

5.4.3 Video Plan

Channel Selection: configure video recording plan for 2 channels of visible light and thermal imaging, and the 2 channel configuration are independent of each other.

Mode: supports three modes, selecting from *Close Video*, *Alarm Recording* (default), and *Scheduled Recording*.

■Close Video: select to close the recording, the channel recording will no longer be recorded in the SD card.

■Alarm Recording: select alarm recording, check linkage recording in the alarm setting interface, and there will be alarm recording of this channel in the SD card.

■Scheduled Recording: choose to record by time period according to plan, and ordinary video will be recorded according to the set time period.

The schedule is mainly to facilitate the one click synchronization of the time period set in the general schedule when setting the deployment time and video recording / capture plan. The general schedule can be edited (drag and click operation) or reset with one click.




Figure 5.26 Storage Management-Video Plan

5.4.4 Capture Plan

Channel Selection: configure video recording plan for 2 channels of visible light and thermal imaging, and the 2 channel configuration items are independent of each other.

Mode: supports three modes of *Close Snap*, *Alarm Snapping*, and *Scheduled Snapping*.

Storage Method: *Upload FTP* and *Local Storage Device* (SD card storage) are optional. You can choose one at will or two at the same time.

- Close Snap: choose to close the capture, and all the capture functions stored in the SD card or FTP will be closed.
- Alarm Snapping: select the alarm linkage capture, check the linkage to take pictures in the alarm setting interface, and there will be alarm pictures of this channel in the SD card or FTP storage directory.
- Scheduled Snapping: capture ordinary pictures according to the set time period to SD card or FTP storage directory.

The schedule is mainly to facilitate the one click synchronization of the time period set in the general schedule when setting the deployment time and video recording / capture plan. The general schedule can be edited (drag and click operation) or reset with one click.




Figure 5.27 Storage Management-Capture Plan

5.5 System Management

5.5.1 Local Setting

It includes *Local Setting* and setting for Date and Time.

5.5.1.1 Local Setting

The local setting interface sets device name, system language and video format, as shown in the figure below:

The screenshot shows a web interface for 'Local Setting' and 'Date And Time'. The 'Local Setting' tab is active. There are three input fields: 'Device Name' with the value 'Thermal Camera', 'Language' with a dropdown menu showing 'english', and 'Video Standard' with a dropdown menu showing '50HZ'. At the bottom, there are three buttons: 'Default', 'Refresh', and 'Confirm'.

Figure 5.28 System Management-Local Setting

Parameters	Descriptions
1 Device Name	the device name can be set
2 Language	the system language, including Chinese and English
3 Video Formats	display the video formats, including 50Hz and 60Hz

Table 5-1 Parameter Description of Local Setting

5.5.1.2 Date and Time

The date and time setting interface sets date&time format, time zone, system time and NTP, as shown in the figure below:

Figure 5.29 System Management-Date and Time Setting

Parameters	Descriptions
1 Date Format	date format in system display
2 Time Format	time format in system display, including 24-hour format and 12-hour format
3 Time Zone	The time zone where the device is located
4 System Time	The present system time Click Synchronous PC, then the time is adjusted based on the PC time.
5 NTP	To synchronize time with the NTP server, enable the NTP function. Choose this option to enable NTP function.
6 NTP Server	The IP address of NTP server
7 Port	Port of NTP server
8 Update Cycle	Interval at which the device synchronizes time with the NTP server

Table 5-2 Parameter Description of Date & Time

5.5.2 User Management

5.5.2.1 User Management

User management can only be performed when the user has user management authority.

5.5.2.1.1 User

1. The system has a default user admin, admin belongs to the highest authority user by default (admin users cannot be deleted). The admin can add ordinary user or operator, but can not add administrator.
2. The admin user change his/her own password and delete or modify non-admin users. The operator can change his/her own password or change/delete the ordinary users. The ordinary user does not have user management rights, the ordinary user can only change his/her own password.




Figure 5.31 User Management-User Interface

5.5.2.1.1 User Group

1. There are three levels of user group: administrator, operator and ordinary user. Adding, changing or deleting new user group is not supported.
2. Only the admin can view or change the authority of user group, and different user groups have different operation authorities. The authority of admin can not be changed, but can reassign the authorities to users of other levels.

As shown in the figure below.




Figure 5.32 User Management-User Group Interface (Admin)




Figure 5.33 User Management-Authority Assignment (Admin)

Note: User management adopts two levels of user group and user. User names cannot be repeated. A user can only belong to one group, and the user's authority is consistent with that of the user group it belongs to.

5.5.2.2 ONVIF User

- 1) The default ONVIF user is admin, who can change admin's password, (password is admin by default), but can not delete admin users.
- 2) The admin can add other ONVIF users.
- 3) Turn off ONVIF authentication, when the camera is connected with NVR via ONVIF, user name and password check is not needed. Turn on ONVIF authentication, and the user name and password is needed when connected.




Figure 5.34 User Management-ONVIF User Interface

5.5.3 Safety Management

5.5.3.1 IP Rights

In order to strengthen the network security of the device and protect the device data, the user who is allowed to access the device through the IP authority can be set.

Whitelist: the device can only be accessed using the IP host in the whitelist, otherwise it can not be accessed. (Edit and delete the added IP address)




Figure 5.35 Safety Management-IP Right Interface

5.5.3.2 HTTPS

The signed certificate can be uploaded and installed through HTTPS, so that the PC can log in to the device normally through HTTPS to ensure the security of communication data.

Steps:

1. Enable HTTPS.
2. Import the certificate and certificate key.
3. Click *Confirm*, and the setting for the device will take effect after restarting.




Figure 5.36 Safety Management-HTTPS Interface

5.5.3.3 RTSP Authentication

The authentication method for the media stream can be set to ensure the security of the data in the process of streaming media transmission.

Three authentication modes:

None: no authentication.

Digest: digest authentication.

Basic: basic authentication.




Figure 5.37 Safety Management-RTSP Authentication

5.6 System Maintenance

5.6.1 Auto Maintenance

■ Automatic maintenance can set the automatic restart time, and the system will restart according to the set time period.

1. Turn on the enable.
2. Select the day of the week and the time.
3. Click *Confirm* to save the settings.

Manual Reboot:

■ Click *Reboot* to manually restart the device.




Figure 5.38 System Maintenance-Auto Maintenance

5.6.2 Backup and Restore

The *Recover Default Configuration* and *Factory Data Reset* operations involve restoring the configuration to the default and factory settings. Please operate with caution.

- Clicking *Recover Default Configuration*, all other configurations will be restored to their default values except for the network IP address and user management information.
- Click *Factory Data Reset* to completely restore the device parameters to the factory state.

Import and Export:

- Import: click *Select File* to select a config file, click *Import* and the function will take effect after camera restart.
- Export: click *Export Config* to export the current configuration to the specified path.
- Export Default Config: click *Export Default Config* to export to the specified default path.

Note: the default download path is the browser's download folder.




Figure 5.39 System Maintenance-Backup and Restore

5.6.3 System Upgrade

System upgrade steps:

1. Click *Import*, select the upgrade file of *.zip type, and click *Upgrade*.
2. Please **do not power off, disconnect the network, restart or turn off the camera** during the upgrade process.
3. After the upgrade is complete, it will automatically return to the login page.




Figure 5.40 System Maintenance-System Upgrade

5.6.4 Version Information

Display system hardware features, software version, release date and other related information. Please refer to the actual situation.



Version Information	
Device Type	
Device PN	IRS-FD225-T3D2A004FFL-A1
Device SN	CB1490005
Thermal Firmware	0.0.2.16.20211022
Version	
Software Version	3.1.01.19, 2022-01-08
Web Version	1.2.8

Figure 5.41 System Maintenance-Version Information

5.6.5 System Log

View system operation, configuration operation, alarm event, temperature alarm, video operation, user management, network event, clearing log, storage management and other log information; See the following figure:

System log

Start Time End Time

Type

Index	User	Type	content	Time Date
1	System	Alarm Event	SD Card Exception	2022-01-26 18:19:44
2	System	Alarm Event	SD Card Exception	2022-01-26 18:19:41
3	System	Alarm Event	SD Card Exception	2022-01-26 18:19:38
4	System	Alarm Event	SD Card Exception	2022-01-26 18:19:35
5	System	Alarm Event	SD Card Exception	2022-01-26 18:19:32
6	System	Alarm Event	SD Card Exception	2022-01-26 18:19:29
7	System	Alarm Event	SD Card Exception	2022-01-26 18:19:26
8	System	Alarm Event	SD Card Exception	2022-01-26 18:19:23
9	System	Alarm Event	SD Card Exception	2022-01-26 18:19:20

Total 9982 ...

Figure 5.42 System Maintenance-System Log Interface

5.6.6 Online Users

View the user information of web login, as shown in the figure below.

Online Users

Index	User Name	IP Address	User Operation Time
1	admin	10.10.20.190:56214	2022-01-26 18:21:48

Figure 5.43 System Maintenance-Online User

6. Playback

6.1 Play SD Card Videos/Images

Channel Switch: select channel 1 (visible light) or channel 2 (thermal imaging) video/picture for playback.

6.1.1 SD card video playback:

Steps:

1. Select SD card as video source, video as file type, the date with recording as the date (the current day is displayed by default), and click Retrieve. All the video of this day will be displayed in the retrieved file list, as shown in the figure below:




Figure 6.1 Playback-Play SD Card Videos

2. Select a video and click the play icon (there are two play icons here, one is behind the video file list

 and the other is below the video timeline ). The video starts to play; click to select a video file and play on the video broadcasting area.



: Play the next video.





: Play the last video.




: Click on a certain time point on the video time axis, and the video will jump to the corresponding time point for playback.

Recording Type: there are two types of recordings: general and alarm. The recording file search will display these two types of recordings by default, and you can check one of the recording types separately for search. (The green circle displayed after the video file indicates general video, and the red circle indicates alarm video)

Video Download: video files like PAV and mp4 is supported. Click the download icon   behind the video list to download the current video files. The download video files will display on the bottom, double click to play. Single or multiple video download is supported. (Tick several video files or *Select All*, and click *Download* to select the format).

Show IVS Information: after enabled, the smart information overlay will be displayed in the playback video.




Playback video sound switch : after enabled, the sound can be heard when the video is played.

6.1.2 SD card image playback:

Steps:

Select SD card as video source, image as file type, date with image (the day is displayed by default), and click *Retrieve*. All image files for this day will be displayed in the search file list, as shown in the figure below:



No Data



Figure 6.2 Playback-Play SD Card Images



Click an image in the file list to play the image. Click the icon at the bottom right to play images one by one in order from the current position.



: Play the next image.



: Play the last image.

Capture Type: it includes two types of images: general and alarm. The image file search displays these two types of images by default. You can check one of the image types separately for retrieval. (The green circle displayed after the picture file indicates the general capture, and the red circle indicates the alarm capture).

Picture Download: you can select one or several images to download. Select all to download all images of a certain column; the downloaded images will be displayed at the bottom, and you can view them after double-clicking.

6.2 Play Local Videos/Images

Steps:

Select local as video source, video/image for file type, and click *Select Local Files* icon. Select a video/image file on the computer, and click the play icon, as shown in the figure below:




Figure 6.3 Playback-Play Local Videos

The image files can be displayed after being selected, see the following figure:




Figure 6.4 Playback-Play Local Image